

Rolling in Vinyl Transcript

[00:00:02] All right, so first, before you start, you want to make sure that you have on gloves to keep away fingerprints from getting on the vinyl Keeps the vinyl clean.

[00:00:11] And there's two different types of spline that we have here. This spline is spline for the vinyl and this spline is for the screen it's more flat in round-shaped. So first thing you do is you put the vinyl on top of the vent. Make sure it's straight, no creases or wrinkles. And then what you do now is you put it like at the corner. So that whenever you put the other part down, you make like a square right there. You just lay down and you punch it in. Then you cut. Again, leaving that square part right here. And you do the same with the bottom piece.

[00:01:18] And this holds the final down, so whenever you vinyl it down, it doesn't move. And just cut that. So now what I'm going to do is I'm going to roll it in. Now as I'm rolling, I'm pulling it upward just a little bit. Not too much. You're all at once and then go back over it.

[00:01:46] Make sure that it's laid in tight. In here, you want to have make it look like a little crease right here. That's how you know that you laid it in right.

[00:01:58] And do the same with the other side. You pull it up just a little bit.

[00:02:14] Roll it in again, this that crease right here, which you want to have.

[00:02:22] And with the bottom, you just pull it down, you have to put a bottom down a little tighter. Pulling in as I go again, the crease. Same with the other side. Again, the crease is here. See how it looks straight no creases. It makes it easier to lay down on the on the sides.

[00:03:13] So, again, make sure you keep that square at the top just in case, like you need to pull back. Sometimes you mess up and you want to use a little small screwdriver just to pull it up here if you mess up. Just lay it down and roll in.

[00:03:43] And you cut it again leaving a square.

[00:03:57] Roll it in tight, sometimes you want to check the corners to make sure that is all the way down. Straight, no creases, no fingerprints. And you do the same with the other side. Again, leaving it square here. Roll it in tight. We want to check the corners, make sure they're down all the way. Now what you do is you cut it, you put the knife on top of the the spline. Want to make sure that you don't cut the inside. So you got to point it. Pull it.

[00:05:50] This is clean, no fingerprints, no wrinkles, and that's it.